

INSTALLATION INSTRUCTIONS.

293 PUSH PAD SINGLE PANIC BOLT.

INSTALLATION INSTRUCTIONS

Panic devices manufactured in accordance with EN 179:2008, will provide a high degree of safety and reasonable security provided they are fitted to doors and frames in good condition. It is not recommended that panic devices be fitted to hollow core doors. The door/doors should be checked to ensure correct hanging and freedom from binding. This standard panic bolt is suitable for right hand and left hand opening doors of upto 2440mm (8'-0") high x 1220mm (4'-0") wide. For doors of upto 3360mm (11'-0") high use top shoot Cat. No. P0801 plus an additional shoot guide Cat. No. P0201.

Note that if a single panic bolt is to be fitted on double rebated doors together with a panic latch. A revised panic bolt fixing position is shown on the panic latch installation instructions sheet.

Unless specially designed by the manufacturer panic devices are not intended for use on double action (double swing) doors.

WARNING The safety features of this product are essential to its compliance with EN 179:2008. No modification of any kind, other than described in these instructions are permitted.

FITTING PROCEDURE

Text instruction letter also refers to the relevant details or dimension shown on the diagram.

A. Determine the height of the push pad between 900mm and 1100mm from floor level. Mark this position on the jamb adjacent to the door. To establish the mounting position for the panic bolt operating unit 10mm from the jamb. Place the template on the door and align the push pad height and the rebate line with the jamb and drill the fixing holes required. Remove the template and temporarily fix the operating unit.

B. Measure bottom (short) shoot length dimension B accurately. Subtract 8mm and cut plain end of tube to length. Drive bottom (short) shoot end plug Cat. No. P0601 into cut end. Plug must be driven in fully against the tube end.

C. Measure top (long) shoot length dimension C accurately. Subtract 54mm and cut plain end of tube to length. Drive top (long) shoot end plug Cat. No. P0501 into cut end.

D. Remove the panic bolt operating unit from door and fit top and bottom shoot tubes to panic bolt unit spigots and retain with socket head screws positioned adjacent to the door face.

E. Position shoot guides Cat. No. P0201 on shoot tubes. Refit panic bolt unit and fit guides to the door using the round head screws. Shoots must be vertical and panic bolt unit and guides must be in alignment.

F. Keeping the operating pad fully depressed locate the top trip assembly Cat. No. P1201 on the top shoot end. Use a 3mm thick spacer between the end of the top shoot and the underside of the head frame to ensure that the shoot is fully withdrawn and secure the top trip/guide assembly to the door.

G. The head keep plate Cat. No. P0401 should be fitted flush in the head frame and with its narrow edge level with the door rebate. Use the short c'sk head screws provided.

H. Easy clean floor socket Cat. No. P0301 for solid floors should be fitted flush with the finished floor surface and with its edge level with the inside door face. Alternative floor plate Cat. No. P1301 for wooden floors must be fitted flush with the finished floor surface and with its narrow edge level with the door face.

I. Operate the panic bolt and ensure that the top trip device holds both shoots in the fully withdrawn position when the door is open.

J. Close the door and ensure that the top trip releases the shoots to engage fully in both top and bottom keeps and holds the door firmly closed in its rebate.

K. Finally test the panic bolt to ensure that when the push pad is operated the door opens immediately and swings freely. When the door is open the shoots are held fully withdrawn and when closed the shoots engage fully in the keepers and hold the door securely closed.

L. Remove backing paper and fit self adhesive nameplate into the recessed location in the body casting to cover top fixing screws.

Fit green self adhesive "Push Bar to Open" sign onto the door immediately above the push bar.

MAINTENANCE

Weekly. Check for correct operation of the single panic bolt and that the bolts fully engage with both keeps. Ensure that the keeps are free from obstruction.

3 Monthly. Check that all fixings are secure.

IMPORTANT

This equipment must be installed by a competent installer. These fixing instructions must be supplied to the user by the installer when the installation is complete. If these instructions are disregarded then no responsibility can be accepted by the manufacturers.

