HOCHIKI TRUE LOOP EMULATOR USER MANUAL



2 Hochiki TE-TLE True Loop Emulator – User Manual

If you have any queries regarding this product, or its functionality, please contact your nearest Hochiki office:

Hochiki Europe (UK) Limited Grosvenor Road Gillingham Business Park Gillingham Kent ME8 0SA

- Tel: +44 (0) 1634 260133
- Fax: +44 (0) 1634 260132
- Web: http://www.hochikieurope.com
- Email: psupport@hochikieurope.com

Hochiki America Corporation 7051 Village Drive, Suite 100 Buena Park CA 90621-2268

- Tel: +1-714-522-2246
- Fax: +1-714-522-2268
- Web: http://www.hochiki.com
- Email: technicalsupport@hochiki.com

©2001-2004 Hochiki Europe (UK) Ltd. All rights reserved. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, without the prior permission in writing of Hochiki Europe (UK) Ltd.

Hochiki Europe (UK) Limited reserves the right to alter the specifications of its products from time to time without notice. Although every effort has been made to ensure the accuracy of the information contained in this document it is not warranted or represented by Hochiki Europe (UK) Limited to be a complete and up-to-date description.

Document Details:

Title:	Hochiki TE-TLE True Loop Emulator - User Manual
Issue	3.0
Issue Date	March 2004
Part No.	2-3-0-416

This manual covers the TE-TLE software versions 1.00 - 2.02

Table of Contents

Table of Contents	3
Introduction	5
Overview	5
Conventions Used in This Manual	5
Setting Up the Emulator Hardware	7
TE-TLE True Loop Emulator Equipment List	7
Equipment Included	7
Equipment Required (not supplied)	7
The Interface	7
Switching the Interface On	8
Interface RAM requirements	8
Connecting to the Computer	9
Connecting to a Control Panel	9
Polling	9
Example Connections	10
Installing the Emulator Software	11
Requirements for the Computer	11
Installing from the CD-ROM	11
Windows 2000	12
Starting the Emulator Software	12
RAM Warning Message	12
Using the True Loop Emulator Software	13
Introduction	13
Starting the Software for the First Time	13
The Main Screen Areas	14
Loop Display	15
Creating Devices	15
Device Ranges	15
Selecting a Device from Menu	16
Selecting a Device from New Device window	17
Device Type Families	18
Removing Devices	18
Changing Device States	19
Device Properties	20
Refresh Button	21
Auto-Refresh Button	21
Saving Configuration Data	23
Configuring Devices	25
Opening Configuration Data	25

E

Working with More than One Device at a Time	25
Ramping the Analogue Value	26
Setting Current Levels	27
Setting Devices as 'Missing'	28
Open Circuits	28
Base Sounders	29
Introduction	29
Adding Base Sounders	29
Base Sounder Properties	30
Connecting the PC to the Interface	31
Selecting a PC Communications Port	31
Running the Interface without a PC	32
Global Commands	33
The Event Record	36
Polling Start & Polling Stop Events	36
Examining the Event Record	37
Saving the Event Record	37
The Data Log	37
Enable Data Log Functions	38
Scripting	39
Introduction	40
Working with Scripts	40
Index	42
	• —

Introduction

Overview

The TE-TLE (*Test Equipment - True Loop Emulator*) system emulates Hochiki addressable devices that use the Hochiki ESP protocol.



It uses a combination of hardware and software to achieve this. An Interface connects the computer to a control panel. Each Interface can run up to four loops of devices and the software can drive up to two Interfaces. Thus it is possible to emulate up to eight loops of devices simultaneously.



5

The online Help system contains more extensive information than this manual and may be more up to date. It can be accessed by selecting Contents from the Help menu of the program or by pressing the F1 key at any time.

This manual assumes that the reader is familiar with the capabilities of Hochiki ESP addressable devices.

Conventions Used in This Manual

When the manual describes text to be entered at the keyboard, keys to be pressed, or a series of menu options this typeface is used. For example, if the user is asked to press the 'Alt' key and the '3' key simultaneously the manual would show this as Alt+3. Similarly, the menu options to display the **Options** window would be shown as File, Options.

If a button or checkbox on screen is described, this will be shown thus: Save button, or Ramp checkbox.

Setting Up the Emulator Hardware

TE-TLE True Loop Emulator Equipment List

Equipment Included

The following items are supplied within the TE-TLE package. Please unpack the system and check that all of the following are included:

- True Loop Emulator module (box)
- Serial Cable (for connection to PC)
- Power Supply Unit (PSU) supplying an output of 12V DC from an input range of 190-264V AC at 65mA - for use in Europe only. For USA, use PSU Model WP1112-760' supplying an output of 12V DC from an input range of 100 - 240V AC.
- Hochiki TE-TLE True Loop Emulator User Manual (this manual)
- Hochiki TE-TLE True Loop Emulator Software CD-ROM

Equipment Required (not supplied)

- Wiring to connect the TE-TLE to a suitable control panel
- PC or laptop required to run the emulator software

NOTE: The 3-pin plug supplied with the PSU is of the UK type. Please use an appropriate adapter if using the TE-TLE outside of the UK. Please ensure that only the supplied PSU (or the specified PSU for the USA, as above) is used with the TE-TLE. Hochiki Europe accepts no liability for damage caused by using any form of power supply other than that supplied or specified.

The Interface

The 'Interface' is the box or module that interfaces between the computer running the True Loop Emulator program and a Control Panel. However, it is more than just an electrical interface; it contains a microprocessor that carries out much of the processing of the system.

The Interface has eight pairs of terminals grouped into four loops and eight LED's, one for each pair of terminals. The function of the LED's varies as described below.

F

LED	Meaning
Off	No voltage on loop
Blinking	Voltage & polling on loop
On	Voltage but no polling

Any changes that happen at the computer end are almost immediately mirrored at the Interface. However, if a large number of changes are required at the same time (for instance, lots of devices added at the same time), then there may be a small delay before all the information is transmitted to the Interface. In this case, a message is shown in the bottom status bar of "Downloading device status...".

Also on the front panel there is an RS-232 9-way D-type (DB9) connector to connect with a computer, a socket for power with a Power LED and an earth stud.

NOTE: To comply with EMC regulations the Interface must be connected to a suitable earthing source. The earth stud is provided on the front panel for this purpose.

Switching the Interface On

When the mains power supply is plugged in and connected to the Interface, it starts up and runs some internal diagnostics.

While in this state, the Power LED is off and the other LED's scan left and right. The Loop Terminals are set to Open Circuit and do not generate any current responses.

Interface RAM requirements

To run the TE-TLE software version 2.0 or later requires at least 4 megabits of RAM memory to be present within the interface. If the interface has less RAM than this you will be presented with a warning on-screen informing you of this the first time you run the software. This warning is shown in the status bar above the Start Button in Windows:

112	113	114	115	116	117	118	119	120
The Inter	face does not	have enough	memory for th	is version of t	he program. D	ouble-click he	re for help.	
Sta	rt		True Lo	oop E				

You can double-click here to display a page within the software's help files explaining further.

As a guide, any interfaces produced by Hochiki Europe with 'cream' coloured cases will most likely not have the extended RAM capacity. In this instance you can return your interface to either Hochiki Europe (UK) Ltd or Hochiki America Corporation who will undertake to increase the RAM memory **FREE OF CHARGE**. Please contact your local Hochiki office for further details (see page 2 for contact details).

Interface	RAM	Compatible Software Version
CREAM coloured case	1 megabit	1.0 only (but can be upgraded)
GREY coloured case	4 megabit	1.0 to 2.01

Connecting to the Computer

The computer and Interface are connected by a serial RS-232 ("straight") cable between the 9-way D-type connector on the Interface to a serial port on the computer.

The True Loop Emulator must be informed as to which serial port is being used. The **PC Communications** property page of the **Options** dialogue box (from **File**, **Options**) is used to accomplish this (see "Connecting the PC to the Interface" on page 31.

Connecting to a Control Panel

The Interface contains an electrical interface for four loops. Each loop consists of a pair of Drive terminals (+ and -) and a pair of Return terminals (+ and -).

Each loop is isolated from the others. When a loop is set to be Open Circuit, the Drive and Return sections are isolated from each other. When a loop is set with no Open Circuits, the Drive and Return sections are directly connected to each other.

The Drive terminals of a loop from the Control Panel should be connected to the Drive terminals of a loop on the Interface. The Return terminals on the Interface should be connected to the Return terminals of the same loop on the Control Panel.

NOTE: Always ensure the loop polarity at the Interface is correct, as indicated by the + and - labelling.

When a Control Panel has been connected to the appropriate terminals on the Interface and has been switched on, the LED's indicate voltage and polling information for each loop.

Polling

As the Control Panel polls each address, the computer loop display for that address 'blinks' (unless this has been turned off in the *Options* dialogue box) and a summary of polling is shown in the bottom status bar.

Some Control Panel commands apply to a range of addresses; these are indicated by all relevant addresses 'blinking' at the same time.

F

Example Connections

The following diagram shows how the Interface should be connected to a PC and a Fire Alarm Control Panel:



(running Emulator software)

Installing the Emulator Software

Requirements for the Computer

The table below shows both the minimum and the recommended specification for the computer that is going to be used:

	Minimum	Recommended
Processor	Pentium 90	Pentium 200 or faster
Operating System	Windows 95, 98, NT4, XP- home or 2000 Professional	Windows 95 or above
Hard disk	5 Mbytes free	5 Mbytes free
Screen Resolution	800 x 600 pixels 16 colours	1024 x 768 pixels or more 256 colours
Connections	1 serial port per interface	1 serial port per interface Mouse

NOTE: The software is very display-orientated. Use the highest screen resolution available and use the software full-screen ("maximised") if possible.

Installing from the CD-ROM

- Insert the *True Loop Emulator* CD-ROM.
- If "auto insert notification" is enabled, the installation program will automatically start.
- If nothing has happened within thirty seconds after inserting the CD-ROM, then run the installation program called "SETUP.EXE" that is on the CD-ROM.

This can be done by selecting the Run menu item on the Start Menu, then typing D:\SETUP.EXE (replacing the D with the drive letter of your CD-ROM drive if necessary) and pressing the **Enter** key. Alternatively, Use Windows Explorer to explore the contents of the CD and double-click the SETUP.EXE file.

Once the installation program starts, it asks for confirmation that you wish to install the True Loop Emulator software. Once you have selected Yes, just follow the on-screen instructions.

On completing the installation, you are given the opportunity to start the Software immediately.

NOTE: The software does not run on Windows 3.x or Windows for Workgroups.

F

Windows 2000

Depending on configuration of your system, the software may need to be installed under an "Administrator" as well as a "User" profile.

Starting the Emulator Software

The True Loop Emulator software can be started by selecting the **True Loop Emulator** menu item in the **Programs** section of the Start Menu. If the installation used the default settings, this menu item will be in a sub-menu called **Hochiki**.

Alternatively, once you have saved a configuration data file, you can start the software by double clicking on the configuration data file.

The on-line Help documents several other ways to start the software (search for *Start*), but the Start Menu method will do for now.

RAM Warning Message

To run the TE-TLE software version 2.0 or later requires at least 4 megabits of RAM memory to be present within the interface. If the interface has less RAM than this you will be presented with a warning on-screen informing you of this the first time you run the software (see "Interface RAM requirements" on page 8).

Using the True Loop Emulator Software

Introduction

This chapter is a step-by-step guide on how to use the Emulator Software for the first time. It covers starting and configuring the software and briefly describes some of the main areas of the system.

These instructions can be followed without the Interface being connected to the computer, so for the time being please disconnect the serial cable from the PC.

Starting the Software for the First Time

If the software is not already running, select **Loop Emulator** from the entry in the **Programs** menu from the **Start** button. By default, this will be on the **Hochiki** sub-menu, but it may have been installed elsewhere.

The software displays a "Welcome" message when is started for the first time:



For now, just click on the **OK** button. The main window can now be seen.

F

The Main Screen Areas

When the program first starts, the main window looks similar that shown below:

FIRE EUR DEVICE	le Edit Device Events Script Help														
New Open	Image: New Open Save Image: New Open Image: New														
Optical Heat	Applical Heat Ionisation Multi Calport Model Base														
Loop 1 Loop 2	00001 Loop 2 Loop 2 Loop 4 Loop 5 Loop 5 Loop 5 Loop 2 Loop 2 Loop 9 Events Sgipt														
Loop 1 Address 5															
Global 1	1	2	3	4	5	6	7	9	9	10	11	12	13	14	15
16 1	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
		24	-	~	27	~	~						c.	15	17
132 13		34	133	130		130		140			143	94	140	140	4/
48 4	49	50	51	52	53	54	55	56	57	158	59	60	61	62	63
80 8	31	82	83	84	85	86	87	88	89	90	91	92	93	94	95
	7	99	99	100	101	102	103	104	105	106	107	108	109	110	111
112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127

There are two rows of tool buttons underneath the row of menu options. These icons are short cuts to the most common functions of the Emulator:

	Ê			\bowtie	\times	X					₿.	k	k	k	2	k
New	Open	Save	Print	Undo	Delete	Cut	Сору	Paste	Run	Stop	Pointer	Alarm	Pre-Alarm	Normal	Fault	Missing
Optical	Heat	Ionisation	Multi	Callpoint	Module	▼ Bas	e 🗸									

These button and their functions will be described in more detail later on in this manual.

If the screen resolution of the computer is less than 1024 by 768 pixels, the buttons may take seem too large in proportion to the main screen. They may be reduced in size by removing the caption or by using smaller pictures on the buttons. Right-click on any button to obtain a button-size menu or use the **Display** property page of the **Options** dialogue box from File menu (see "Display Options" on page 16).

There is also a row of tabs below the buttons:

Loop 1 Loop 2 Loop 3 Loop 4 Loop 5 Loop 6 Loop 7 Loop 8 Events Script

These select different pages for the rest of the window. There are eight pages for loops, one for the Event Record and one for Scripts. The tab for the page that is currently displayed is shown as being in front of the others.

Loop Display

Each loop tab displays a page for a loop. The True Loop Emulator can emulate up to eight loops. The loop display consists of 127 address positions, a 'global' position and two status bars above and below the address positions.

Move the mouse over the address positions and watch the top status bar. The status bar contains the loop number and address of the position that the mouse is over.

Loop 1 Address 72

Later on, this status bar will contain further information on the device that is at this address.

Most of the buttons are enabled while a loop is displayed, although some are currently disabled. The **New**, **Open**, **Save** and **Print** buttons are the standard Windows buttons. The buttons that have pictures of different devices are called the Device Buttons. These are used to put emulated devices at addresses. Your system may have different device buttons to those shown in the pictures in this manual.

Creating Devices

The Emulator software allows the user to select and position icons that represent various fire detection devices.

Device Ranges

The range of devices available from the device drop-down lists on the main screen is dependent on the Devices setting. As default, the devices initially available are in line with the country code of the host PC. Hochiki Europe devices, Hochiki America devices or a combination of both can be selected.

This is achieved from the **Display** tab on the **Options** dialogue window (File, Options):

E



Display Options

Checking the "Hochiki America Corporation" checkbox in the Devices section will result in only Hochiki America devices being available for selection, and vice versa, checking the "Hochiki Europe (UK) Ltd" checkbox will result in only Hochiki Europe devices being available. Checking both checkboxes here will result in both product ranges being available.

Selecting a Device from Menu

Move the mouse over the first device button and then wait until a 'tip' appears. This describes the device in more detail. If this device is not an analogue smoke or heat sensor on your system, choose another button.



Click on this button and move the mouse over an address position, in this example we will use address number 72. Notice that the mouse pointer has changed into the shape of the device. Now click on address position 72. A picture of the device is drawn at the address position with a green background and a dark blue outline.



The True Loop Emulator is now emulating a device at address 72 on loop 1. The green background indicates that the device is in a 'normal' state. The dark blue outline indicates

that the address position is currently 'selected'. The top status bar now has more information in it:

Loop 1 Address 72; ALG-E (Optical Sensor); Normal; Optical = 0.00 %/m

The mouse pointer is still the picture of the device and it can be used to put the same type of device at other addresses on this loop.

Selecting a Device from New Device window

You can also add a new device by right-clicking with the mouse on one of the grid squares and selecting **New Device** from the pop-up menu.



The New Device dialogue box will be displayed. Click on New Device to display a device 'tree'. You can select any device from here; each range of devices is shown as a branch similar to Windows Explorer. Each branch can be expanded or collapsed using the plus and minus symbols:



Highlight the device and click on the **OK** button to add this device to the grid.

17

Device Type Families

Some Device Buttons have an arrow on their right-hand side. This indicates that there is a 'family' of device types and that the button shows just one member from the family. For example, click on the arrow to the side of the **Callpoint** button, to see the drop-down list of device types:



Click on an item in the list to change the picture on the device button.



Now use this to add a device at another address; for example address number 18.

Removing Devices

If for any reason you place a device at the wrong address, simply follow these steps to remove it:

- Change the mouse shape back to the pointer by clicking on the **Pointer** button (white arrow).
- Click on the device address you wish to remove so that it is highlighted with the blue lines.
- Click on the **Delete** button the device icon will disappear from the Address Square denoting the device has been removed from the loop.

Other ways to delete selected devices are

- Press the **Delete** key on the keyboard whilst device is highlighted
- Select Delete from the Edit menu or Device menu whilst device is highlighted
- Select Delete from the Properties pop-up menu when right-mouse clicking the device.

Select No Device from the New Device option from the Properties menu when right-mouse clicking the device.

Changing Device States

Now look at the buttons that have arrows in different colours:



These are used to set devices into different 'states'. A device can be in alarm if it has an analogue channel or input channel. A device can be in pre-alarm if it is not in alarm and has an analogue channel. A device can be in a fault state if it is not in alarm or pre-alarm and if it has a fault on an input channel, an output channel or a 'primary-side' fault. A device is in a normal state if it is not in alarm, in pre-alarm and does not have a fault. The Missing state is described in the next chapter.

Click on the **Alarm** button (red arrow) and move the mouse over the address positions. Note that the mouse pointer changes to a red arrow.

NOTE: If you have difficulty in distinguishing colours, you may wish to change the mouse pointers to those that also display a letter next to them. This can be done on the **Display** tab of the **Options** dialogue box from **File**, **Options** see "Display Options" on page 16).

Now click on the device at address position 72. It changes to a pink background and the status bar now indicates that the device is in alarm.



If there was an Interface connected to the computer and a Control Panel connected to the Interface, the Control Panel would now be indicating an alarm condition.

Next, right-click on the device at address position 72.

NOTE: With the mouse pointer over the address position, depress the right-hand button on the mouse. Keyboard equivalents are the **Windows Menu** key and **SHIFT+F10**.

A context-sensitive menu appears:

F



This is a sub-set of the menu items on the **Device** menu. Only those items that are appropriate are shown. Select the **Normal** menu item to change the device back to the 'Normal' state.

Device Properties

Right-click again on address 72 and pick the **Properties** menu item. This displays a dialogue box that has the properties for the device shown on various pages:

Les Device Properties ACA-E (Multi-sensor) at address 72 on Loop 1.	X
Optical/Heat Optical Heat Qutput EEPROM Device Faults Interrupts Configuration	1 S
Decimal Hexadecimal %/m Fire Point: 190 0xBE 4.50 Fixed Threshold: 190 0xBE 4.50 Variable Threshold: 255 0xFF 6.77 Analogue Value: 61 0x30 0.00 Zero Point: 61 0x3D 0.00 Image: Second 10 10 10	Current Analogue Mode
Auto-Refresh Refresh Set to Normal OK	Close Apply

The tabs across the top of the dialogue box access the different pages here. Each device type will have different pages, appropriate to the capabilities of that device. The device shown above has a page for one analogue channel, for output channels, for the EEPROM contents, for the device faults and for the interrupt status of the device.

The analogue page shows various values in decimal, hexadecimal and in calibrated units. The user can change the decimal forms of some of these. The Control Panel would normally set the Zero Point and Variable Threshold. The user can change the current Analogue Value and the Fire Point.

Refresh Button

Refresh

If the Control Panel (or a Script or Ramping - see later sections in this Manual) changes a device's properties, those properties are not automatically updated in this dialogue box. Instead, the **Refresh** button at the bottom of the screen is enabled:

Clicking on this updates all the properties on the dialogue box to match those of the current device.

Auto-Refresh Button

Auto-Refresh

This button is a toggle button that stays down or up when clicked. When it is down, the dialogue box automatically updates all the device properties whenever a Control Panel, a Script or Ramping changes the properties of the devices.

Click on the **Output** tab to show the Output properties for this device:

	Device Pro	perties							×
	ACA-E (Multi-s	ensor) at address	72 on Loo	p 1.					1.2.2
	Optical/Heat	Optical Heat	<u>O</u> utput	<u>E</u> EPROM	Device <u>F</u> aults	l <u>n</u> terrupts	<u>C</u> onfiguration	1	
	Channel	Active							
	LED	Off							1000
1					1				
		Auto-R	efresh	Refresh	Set to	Normal	OK.	Close	Apply

This particular device type has only one output channel. This channel controls the LED's and is not currently activated by the control panel. The picture to the right shows how the device will look on the screen if the LED's are activated.

Some device types have monitored outputs and can have their outputs activated continuously or intermittently. Below is the property page for such a device:



CHQ-B (Dual Sc	erties ounder Controller) at addres:	s 38 on Loop 1.	-	-	-	K CHQ-B H
Input Uutput Channel	Device <u>F</u> aults I <u>n</u> terrupts Active	Status				
Output 1	Continuous Off Intermittent Off	 OK Open circuit 	C Short Circuit			CHQ-B
Output 2	Continuous Off Intermittent Off	 OK Open circuit 	C Short Circuit			CHQ-B
	Auto-Refresh	Refresh	Set to Normal	OK.	Close	Apply

The user can generate faults on the monitored outputs and see exactly how the outputs are activated.

Now close the **Device Properties** box for this device and display the **Device Properties** dialogue box for the device at address 18.

😓 Device Prop	erties					×
MCP-E/Y (Addre	essable Callpoint) at add	ress 18 on Loop 1				FIRE®
Input Output						
Channel	Active	Status				
Break Glass	C Active	● OK				FIRE®
	Auto-Refresh	Refresh	Set to Normal	0K.	Close	Apply

This device has one input channel that is used to indicate the state of the break glass. The user can set whether this input is active or not. The picture to the right shows how the device will look on the screen if the break glass is activated.

Some device types have monitored inputs. Below is the property page for such a device:

Device Prop CHQ-B (Dual Sc	erties ounder Controller) at addre	s 38 on Loop 1.		K CHQ-B H
Input Dutput	Device <u>F</u> aults I <u>n</u> terrup	s		
Channel	Active	Status		
Input	C Active	OK O Short Circuit O Open circuit		сно-в
	Auto-Refresh	Refresh Set to Normal	OK. Close	Apply

The user can generate a fault on the monitored input, in addition to activating it.

Saving Configuration Data

Click on the Save button to display the Save Configuration Data dialogue box.

NOTE: The **Save** button has a different function if the Event records or Script pages is displayed. In this case, entries on the **File** menu can be used to save configuration data.

Choose an appropriate location and file name and save the data. This will create a file that contains a list of all address positions and what devices are at those addresses. It does not contain the state of the devices. The saved file will have an extension of ".hle".

E

24 Hochiki TE-TLE True Loop Emulator – User Manual

This page is intentionally blank.

Configuring Devices

This chapter assumes that you have just completed the operation in the previous chapter. If not, quickly go through it again, in order to set up the True Loop Emulator system in the way that this chapter expects.

It still assumes that the Interface is not yet connected to the computer, so ensure the serial cable is disconnected from the PC at this point.

Opening Configuration Data

Click on the Open button to display the Open Configuration Data dialogue box.

NOTE: The **Open** button has a different function if the **Event Record** or **Script** pages are displayed. In this case, entries on the **File** menu can be used to open configuration data.

Choose the file name that was used at the end of the previous chapter and open the data. This will put devices in address positions as specified by the file. All devices are set to 'Normal'.

Working with More than One Device at a Time

Click on the **Pointer** button (white arrow) if it is not already depressed.

Now click on address position 1. While holding down the Ctrl key, click on address positions 3 and 5. Note that all three address positions have a dark blue outline that indicates they are 'selected' simultaneously.



Now click on a device button to change the mouse pointer to a device. Use this to click in *one* of the addresses 1, 3 or 5. Note how *all* of the selected addresses now contain the device.



Applying an operation to one of the selected address positions automatically applies to it to the others whenever multiple address positions are selected.

There are menu items on the Edit menu to select all address positions (Select All), to 'un-select' all address positions (Select None) and to selectively select or un-select groups of addresses (Select Some).

It is also possible to select a range of addresses by clicking on the first address position then, while holding down the **shift** key, click on the last address position.

NOTE: You need to revert to the white arrow mouse pointer (by clicking on the **Pointer** button) to change the selection without affecting the state of devices and address positions.

Ramping the Analogue Value

Select address position 72 only. This should have a device in it that has an analogue channel. Display the **Device Properties** dialogue box for this device. Click on the **Set to Normal** button, just to make sure all properties have their default values. Now click on the **Ramp** checkbox.

🔩 Device Properties	×
ALG-E (Optical Sensor) at address 72 on Loop 1.	
Optical Dutput EEPROM Device Faults Interrupts Decimal Hexadecimal %/m Fire Point: 190 4.50 Fixed Threshold: 190 0x8E 4.50 Variable Threshold: 255 0xFF 6.77	
Analogue Value: 61 - 0x3D 0.00	
Zero Point: 61 0x30 0.00	
Image Image go. 51 0x30 0.00 at 1 0x01 0.03 per 10 ±	
Auto-Refresh Refresh Set to Normal OK Cancel A	Apply

This enables several new properties that can be changed by the user. These are used to command the True Loop Emulator to change the analogue value of a device over time. The first value (labelled 'to' in the dialogue box) is the 'target' value. The analogue value will change from the current analogue value to the target analogue value. The change happens in steps; the rate at which it does this is determined by the two values labelled 'at' and 'per'. The 'at' value determines the step height; this is in analogue value units. The 'per' value determines the step width; this is in seconds.



Change the ramp settings to ramp from 61 to 200 at 10 per 5 seconds and then click on the **OK** button. Move the mouse pointer over address 72 and watch the analogue value change in the status bar at the top.

The analogue value will rise until it reaches the programmed value (200 in this instance) and the device will then enter into Pre-Alarm and then into Alarm as it reaches the threshold.

Setting Current Levels

Right-click on address position 72 and highlight the Current Level menu item.

E	لىر يە				
	Properti	ies			
	New dev	ice			
뽇.	Delete			75	176
	Alarm			-	
	Pre-Alarm	n			
	Fault				
88_	Missing			91	92
	Current L	evel	Þ	Minimum (18	mA)
	Create O	pen Circuit befor	e address 72	 Nominal (22 r 	nA)
	Create 0	pen Circuit after	address 72	Maximum (26	(mA)
-			1	Double Addre	ess (37 mA)
104	Ļ	105	106	107	108

E

The sub-menu that is displayed shows the level of current, in milliamps, that the Interface uses to respond to commands from a Control Panel.

The Nominal level is the one that is usually used and corresponds to the typical value of real devices. The Minimum and Maximum levels are the limits of the ESP (Enhanced Systems Protocol) specification and can be used to test Control Panel compliance. The Double Address level is used to emulate two identical devices set to the same address.

Setting Devices as 'Missing'

Click on the **Missing** button (blue arrow). Now use this to click on address position 72. Note that the picture of the device now has a grey background and a blue line through it.



This device is now 'Missing'. It does not respond to commands from a Control Panel. This emulates a 'sensor-removed' condition.

Click on the address position again and see that the device returns. At this point, the device has its 'power-on' flag set and requires the Control Panel to re-initialise the device.

Open Circuits

Right-click on address position 71 and select the **Create Open Circuit before** address 71 menu item. A vertical yellow bar is displayed between address positions 70 and 71 to indicate that an open circuit is being emulated here.

Right-click on address position 73 and select the **Create Open Circuit after** address 73 menu item. A vertical yellow bar is displayed between address positions 73 and 74 to indicate an open circuit is being emulated here.



Note that the device at address 72 is now shown as 'Missing'. This is because there is an open circuit either side of it; thus, it cannot be reached by a Control Panel.

Try using the Missing mouse tool to set the device to 'Not Missing'. It is not allowed because the open circuit conditions are still present.

Right-click on address 73 and select the **Remove Open Circuit after address 73** menu item. Note that the device has now returned.

Base Sounders

Introduction

NOTE: This section is not currently applicable to Hochiki America Device users.

Most Hochiki ESP addressable devices have addresses that are set in the range 1 to 127. Base Sounders are different in that their address can be in the range 1 to 254, or not set at all.

For the purposes of the True Loop Emulator, Base Sounders that have addresses in the range 1 to 127 are defined as a different device type called Wall Sounders and are treated as any other device.

Base Sounders usually have a sensor connected to them. If their address has not been set, they cannot be used until one is connected.

The Loop Display only has address positions for address numbers 1 to 127. When addresses in the range 128 to 254 are needed, the top third of the address position that is 127 less is used. Base Sounders are the only devices that can co-exist with another device at an address position in the emulator. If there is both an Optical Smoke sensor and a Base Sounder at address position 1, for instance, then the smoke sensor has address 1 and the base sounder has address 128 or 'Not Set' if it has not yet been set.

Two different forms of Base Sounder are implemented in the True Loop Emulator. The Preaddressed Base Sounder corresponds to a Base Sounder that has already had address set in the range 128 to 254. The Base Sounder corresponds to a device that has not yet had its address set; this is the device type that would more commonly used, as it is how the device leaves the factory.

All of these devices are grouped within one Device Family and are available from the drop down list accessed via the arrow to the side of the **Base** button.

Adding Base Sounders

This chapter assumes that the Interface is not yet connected to the computer, so ensure that the serial cable is disconnected at this stage.

If necessary, use the **New** button to clear any existing configuration data.

Click on the **Base** device button (not the Pre-addressed Base Sounder or the Wall Sounder). Use this to click on address position 1.

Loop 1 Address Not Set; CHQ-BS (Base Sounder); Normal							
Global	1	2	3	4	5		

F

A Base Sounder is added to the top third of the address position. The top third and the bottom two-thirds of the position now operate independently.

Moving the mouse over the base sounder shows the status of the base sounder in the status bar at the top. Note that the address is shown as 'Not Set'. When the address is correctly set, it will be address position 128.

Now add a smoke sensor to the same address position 1.

Loop 1 Address 1; ALG-E (Optical Sensor); Normal; Optical = 0.00 %/m -							
	2.2.2						
Global	1	2	3	4	5	6	

Moving the mouse over the sensor shows the status of the sensor in the status bar. Rightclick on the sensor to see the menu items available for sensor.

Base Sounder Properties

Right-click on the base sounder to see the menu items available for the base sounder. Select the **Properties** menu item to show the **Properties** dialogue box for the Base Sounder.

😓 Device Properties					×	
CHQ-BS (Base Sounder) at address Not Set on Loop 1.						
Output Groups EEPF	ROM Device <u>F</u> aults				,	
Channel	Status					
Continuous Output	No sound					
Alternate Output 1 (command 0x48)	No sound				••••••	
Alternate Output 2 (command 0x49)	No sound				•••••••	
Volume	10 (85dB)					
	Auto-Refresh Refresh	Set to Normal	0K.	Close	Apply	

This shows the tone and volume settings for the device. As no Control Panel has accessed the device yet, these are all set to their default values.

Connecting the PC to the Interface

Once the user is familiar with the software and its functionality, the PC running the software should be reconnected to the Interface with the serial cable as explained in "Setting Up the Emulator Hardware" on page 7. Once this has been completed, the software connection set-up will need to be configured so that the Interface and PC can communicate with each other.

Selecting a PC Communications Port

Take the File, Options menu options, and then select the **PC Communications** tab. The software will display the following screen:

🔩 Options	×
Panel Communications PC Communications Display	
Connection for Interface for Loops <u>1</u> to 4:	
Not connected	
Connection for Interface for Loops 5 to 8:	
Not connected	
OK Cance	!

The software can handle one or two Interfaces. It does this by employing two COM ports. Each of these ports can be assigned to a set of loops, 1 - 4 and 5 - 8. Use the drop down windows here to select either COM1 or COM2 for each range of loops.

NOTE: If a second interface is NOT fitted (Loops 5 to 8) a connection should NOT be specified, in other words left as "Not Connected".

E

NOTE: A different setting should be selected for each range of loops - they should **not** be set to the same COM number. The software will display a warning to this effect if you attempt this.

Click the **OK** button when this has been completed.

The program that is run in the Interface is downloaded from the computer. Thus, a message is sometimes displayed in the bottom status bar showing "Updating software in Interface..." or "Updating Device Characteristics in Interface..."

Once the PC running the True Loop Emulator software has established communications with the Interface and updated it if necessary, the Power LED on the Interface is turned on. Also, the device and open circuit information is sent from the computer to the Interface and the LED's switch to their usual function (see "Switching the Interface On" on page 8").

Running the Interface without a PC

Once the software has been used to configure the Interface, the PC can be removed, leaving the Interface running with the Control Panel. In this scenario the connection would be as follows:



Control Panel

Please note that the following conditions apply when operating the True Loop Emulator system is this way:

- The Interface will not be able to run Scripts on its own.
- ➤ The Interface must have a constant supply of power. If the power supply is interrupted, the Interface will lose the settings it has been programmed with, the PC will need to be reconnected, and the Interface re-configured.
- The Interface cannot store any data and therefore the PC cannot be reconnected to retrieve events or data logs that occurred whilst it was disconnected.
- The analogue ramping function does not work without the PC connected.

• The Interface can be left connected indefinitely. This is particularly useful in a multipanel or multi-loop scenario, where several panels/loops may need soak testing simultaneously.

Global Commands



Some control panel commands apply to all addresses on a loop. The most recent global command is indicated in the Global position (before address position 1) at the top left of the Loop display screen.

An icon is shown here for each type of global command and more details can be seen in the top status bar by holding the mouse over the icon in the Global position.

Global Command Icons

The various icons shown in the Global position of the main Loop display screen are explained below:

E

Interrupt Level Check

121

This Icon will be displayed when a device creates an interrupt on the system.

Sleep Mode Activate

2

This Icon will be displayed when the system is in sleep mode (low power mode).

Synchronise On

This Icon will be displayed when the system sends a synchronisation on signal to outputs (for example sounder devices).

Synchronise Off



This Icon will be displayed when the system sends a synchronisation off signal to outputs (for example sounder devices).

A/D Conversion

This Icon will be displayed every one second (approx.) indicating that the devices are performing their analogue to digital conversions.

Fire Indicator Synchronisation

This Icon will be displayed when the control panel synchronises the fire indicator LEDs.

Interrupt Disable

This Icon will be displayed when the system disables interrupts to allow certain actions to take place, for example a fire test.

Interrupt Disable Cancellation

This Icon will be displayed when the system interrupts have been re-enabled after a disablement.

Global Find Address

ðů,

This Icon will be displayed when the system is initialising the loop to establish the presence of base sounders.

Global Output

This Icon will be displayed when multiple outputs are operated by the control panel.

E

The Event Record

The Event Record stores all events that happen in the True Loop Emulator system. These include both events generated by the user at the computer and events generated by the Control Panel. The Event Record is always running and its capability is only limited by the amount of memory on the computer; it can usually store 32,000 events.

The online Help system contains a complete list of events that can be generated and their meaning (Search for 'Event Summary').

Polling Start & Polling Stop Events

To reduce the amount of event data recorded in the Event Record, you can specify whether start and stop events are added to the record or ignored. To do this take the **File**,



Options menu options to display the **Options** dialogue window. Select the **Display** tab:

Check or uncheck the **Record Polling Start/Stop** checkbox to specify how these events are recorded.

Examining the Event Record

The Event Record is displayed when the Event Record tab is clicked on the main window. A grid is shown with columns for the date & time of the event, the loop, the addresses, the device type and the event itself.

Loop 1 Loop 2 Loop 3	Loop 4	Loop <u>5</u> Loo	p <u>6</u> Loop	Z Loop & Events Sgript
Date/Time	Loop	Address	Device	Action
▶ 05 Sep 2000 11:26:03				Event Record Started
05 Sep 2000 11:26:18	1			Loop Voltage Removed
05 Sep 2000 11:26:18	2			Loop Voltage Removed
05 Sep 2000 11:26:18	3			Loop Voltage Removed
05 Sep 2000 11:26:18	4			Loop Voltage Removed
05 Sep 2000 11:27:06	1	72	ALG-E	Add New Device: ALG-E (Optical Sensor)
05 Sep 2000 11:27:30	1	18	MCP-E/Y	Add New Device: MCP-E/Y (Addressable Callpoint)
05 Sep 2000 11:27:47	1	72	ALG-E	Setto Alarm
05 Sep 2000 11:28:03	1	72	ALG-E	Setto Normal
05 Sep 2000 11:29:08				Open Configuration data file: C:\My Documents\First Looks.hle
05 Sep 2000 11:29:29	1	1	ALG-E	Add New Device: ALG-E (Optical Sensor)
05 Sep 2000 11:29:29	1	3	ALG-E	Add New Device: ALG-E (Optical Sensor)
05 Sep 2000 11:29:29	1	5	ALG-E	Add New Device: ALG-E (Optical Sensor)
05 Sep 2000 11:30:22	1	1	ALG-E	Delete Device
05 Sep 2000 11:31:15	1	72	ALG-E	Start Analogue Value Ramp: Optical ramp to 0xC8 (4.85 %/m) at 0x0A (0.35 %/m) per 5 seconds
05 Sep 2000 11:33:23	1	72	ALG-E	Set to Missing
05 Sep 2000 11:33:30	1	72	ALG-E	Set to Not Missing
05 Sep 2000 11:33:48	1	70		Add Open Circuit after address
05 Sep 2000 11:33:50	1	73		Add Open Circuit after address
05 Sep 2000 11:34:03	1	73		Remove Open Circuit after address

A description of the event is displayed on right clicking on an event in the grid and selecting the What's This? menu item.

An event can be 'selected' by clicking in the grey margin to the left of an event. More sophisticated selection can be carried out using the **select** some menu item on the **Edit** menu.

Selected events can be copied to the PC's clipboard using the **Copy** button or the **Copy** menu item on the **Edit** menu.

Saving the Event Record

The event record can be saved in a format that can be opened by other programs (for example Microsoft Excel). Click on the **Save** button to choose the file name and location. Either all the events or just the selected ones can be saved. The saved file will have a ".log" extension and is a text file type format.

The Data Log

The Data Log is separate from the Event Record. It is used to log all ESP (Enhanced System Protocol®) commands from the Control Panel and all responses from the Interface. This data is particularly useful to panel manufacturers and developers. Access to this function of the TE-TLE is restricted by a password. This password is available from Hochiki Europe (UK) Ltd **only** to third parties that have previously signed the Hochiki Europe (UK) Confidentiality Agreement in relation to the ESP (Enhanced System Protocol®). If you feel

F

you should have this password please contact Hochiki Europe (UK) Ltd (psupport@hochikieurope.com).

Enable Data Log Functions

To enable this functionality select the File, Options menu options to display the **Options** dialogue window and then select the **Panel Communications** tab:

🖕 Options 🛛 👘	×
Panel Communications PC Communications Display	1
Transmit parity errors Noise Burst: Single device:	l
in any responses to the next 10 📩 polls	L
starting with the next poll of address	l
Transmit checksum errors Noise Burst: Single device:	l
in any responses to the next 10 🗾 polls	L
starting with the next poll of address	l
Enable Data Log functions	
Password:	L
OK Cancel	

Check the **Enable Data Log functions** checkbox and a new field will be displayed, **Password**. Enter the password as supplied by Hochiki Europe (UK) Ltd or Hochiki America Corporation. Once this has been accepted three sub-options from the **Events** menu option will be enabled. These are **Start Data Logging**, **Stop Data Logging** and **Save data log As...**



The Data Log is not always running; it is started and stopped by these commands on the **Events** menu. The Log can store 1,000,000 command/response pairs. After this, older data is deleted to make room as new data is generated.

When the data log has been stopped and there is data in it (the Control Panel has sent some commands), it can be saved as a text file for further processing using the **Save data log As...** command. See the online Help for more details of the file format (search for 'Data Log Format').

This page is intentionally blank.



Scripting

Introduction

Scripting is an advanced topic and should probably be left until you are familiar with other aspects of the True Loop Emulator.

A script is a list of commands that will be executed by the True Loop Emulator. The commands are written in a language that is very similar to the BASIC computer language. This language is quite easy to learn; there are many books available.

The extensions to the language to make it appropriate for the True Loop Emulator are covered in the online Help system (Search for 'Script Command' and 'Script Constants').

There are several sample scripts in the Help system that illustrate techniques and features of scripting (Search for 'Example'). Also available is the "TE-TLE True Loop Emulator - Software Script Guide (Part Number 2-3-0-460) which details all of the script commands used in the Emulator software. Please contact Hochiki Europe (UK) Ltd for a copy of this document.

Working with Scripts

Scripts can be displayed by clicking on the Script tab of the main window. This gives a large area in which to type and edit a script.

A script can be generated by

- Typing one in.
- > Opening a script file (**Open** button or **Open** menu item on **Script** menu).
- Pasting one in from the clipboard (for instance, an example copied there from the Script Examples).
- Translating selected events from the Event Record using the Events button (search for 'Convert Events' in the online Help).

The script can be saved and printed by using the standard buttons or the menu items on the script menu.

The script can be started and stopped by using the **Run** and **Stop** buttons or the menu items on the script menu.

NOTE: See the on-line help system within the True Loop Emulator software for detailed information regarding Scripts. Or alternatively, see the "TE-TLE True Loop Emulator - Software Script Guide" (Part Number 2-3-0-460).



Index

If you cannot find the information you require in this manual, try the software Help system.

A		F	
Address position Alarm Analogue Value	15 18, 27 20	Family Fault File Menu Fire Point	17 18 15 20
В		G	
Base Sounders Button	29 14	Global command	33
С		Н	
Clipboard COM Port Connections Control Panel Conventions Copy	36 8 11 7, 20 6 36	Hard disk Help	11 6
Current Level	27	Installation Interface Interrupt status	11 6, 7 20
Data Log Device Buttons	36 15	L	
Device faults Device Menu Device Properties Display Property Page Double Address Drive	20 19 20 15 28 8	LED Loop Terminals	7 8
Ε		Main Window Maximum Minimum	14 27 27
EEPROM Event Record Example	20 35, 38 38	Missing	28
		New Nominal	29 27

Normal Not Set	16, 19, 25 29	Screen resolution Script Serial port Specification State Status bar	11, 15 20, 38 8, 11 11 18 15
Open Open Circuits Operating System Optically isolated Options Dialogue Box	25 28 11 9 15	T Tab Target Terminal Tone	15 26 7 30
Poll Power LED Power supply Pre-addressed Base Sounder Pre-Alarm Processor Properties	9 8 29 18, 27 11 20	U Updating	31

R

Ramp	20, 26
Rate	26
Refresh	20
Requirements	11
Return	8
RS-232	8

5

Sample	
Save	

V

Variable Threshold	20
	20
Volume	30

W

Wall Sounders	29
Welcome	13

20

E

Ζ

38 24, 36

Zero Point