

FS1610 BASE FIXING INSTRUCTIONS

Remove plinths from the packaging, inside unit. Slide back plinth into position. Locate two of the fixing security screws into the holes which are predrilled. (Note security screws are designed only to be tightened as not to be removed).

Locate the unit into the required position, if the unit is to be base fixed insert punch into the bolt fixing holes in the base of unit and mark the floor where the bolts are to be fixed.

Remove unit and drill two holes where the floor is marked using a 21mm masonry drill bit to a depth of 73mm, remove rawl shields and insert into the holes in floor.

Locate unit back into position, once in position unpack the two fixing blocks and position them so they are in line with the bolt fixing holes. Insert the two bolt fixing caphead bolts through bottom of unit and tighten.

Finally locate the front plinth into position and insert the two security screws provided.