

Thank you for purchasing the Blazepak Fire-Retardant Wallet. To get the greatest satisfaction and protection from this product, please read the information on this sheet and keep it for future reference.

Appearance - Please note that the Blazepak Fire-Retardant Wallet is constructed from high performance materials that are used in industry such as on oil rigs, sports cars and in the aerospace industry. The nature of these materials means that there may be some slight surface blemishes to the aluminised skin. This is quite normal and does not affect the performance of your wallet in any way.

Correct use of your Blazepak Fire-Retardant Wallet. – To open: hold the wallet in place on a flat surface with one hand, whilst opening the flap with your other hand, starting at the far edge to release the hook-and-loop fastener and working your way back towards you.

To close: make sure no objects or papers protrude past inner edge before closing flap. Push flap firmly back with flat of the hand, making sure that the leading edges of the hook-and-loop fastener match up. This will ensure the best possible seal. When closed, apply pressure to entire surface of flap with flat of hand to maximise seal.

Fire Protection, Storage and Location of your Blazepak Fire-Retardant Wallet - This product is designed to withstand temperatures of 400°C whilst maintaining an inner temperature of below 200°C for twenty minutes.

Its purpose is to give extra protection over that achieved by a standard document wallet to help protect documents during the average time that the fire service responds to and extinguishes most domestic fires, provided it is used according to the guidelines outlined in this leaflet.

As fire temperatures can be unpredictable, with certain flammable items burning at intensely high temperatures (such as some non fire-retardant materials used in chairs and settees etc), always store your Blazepak Fire-Retardant Wallet on the lowest secure floor of your home in a convenient drawer, sideboard, filing cabinet or safe at a height of no more than 1.2metres above floor level (4feet). This will ensure that the unit's contents have the best possible chance of surviving intact in the event of fire.

Lifetime After-Fire Guarantee - If a domestic fire damages this product any time after being purchased by you (the original owner), Blazepak will send you a replacement free of charge. Send a photo of the fire-damaged wallet, together with a copy of the report from either your insurance company, The Fire Service or Police to: FREEPOST RLTS-USYJ-ALJC, Blazepak, Nuneaton, CV11 6TA

Guarantee - This product is guaranteed for 12 months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship during this period, the unit will either be replaced, a refund will be given or the unit will be repaired free of charge, from the dealer or source from whom you purchased the unit.

This guarantee is subject to the following provisions:

- The guarantee is only valid within the boundaries of the country of purchase.
- The product must be correctly installed and operated in accordance with the instructions contained in this information leaflet.
- It must be solely for domestic purposes.
- The guarantee does not cover accidental damage or misuse.
- The guarantee will be rendered invalid if the product is re-sold, modified or has been damaged by inexperienced repairs. The manufacturers disclaim any liability for incidental or consequential damages.

This guarantee is in addition to, and does not diminish, your statutory or legal rights. Warning: no computer discs, audio-visual media or photo negatives. Standard fire-resistant wallets are not intended to protect computer diskettes, cartridges and tapes, audio or visual cassettes or discs. For fire-resistant storage of these consult your retailer. No jewellery or valuables: do not store jewellery or valuables in this product. Potential damage to delicate jewellery occurs at temperatures much lower than 200°