

## Donning Poster Dräger PARAT® Hard Case



D-83028-2013



Dräger PARAT® Hard Case

D-92788-2013



Open the yellow handle. When opening, the security seal should break.

D-84550-2013



Open the Hard Case completely. The front filter sealing plug should be automatically removed.

D-84560-2013



Remove the hood from the Hard Case. Pull the hood against the Velcro holder, it will automatically open. The second filter sealing plug will automatically be detached when the hood is removed.

D-84575-2013



Widen the neck seal and pull the hood over your head. The inner head harness automatically adjusts to your head. Ensure that nose and chin sit comfortably in the half mask and that all hair is tucked into the hood.

D-84596-2013



Check the fit of the half mask by closing the front filtering opening with the palm of your hand. If negative pressure is not generated readjust the half mask to ensure a close fit over nose and mouth.

D-92897-2013



Ready for use.

D-84604-2013

