

Honeywell



Model **2040**

Model **2040NW**

THE MEDIA PROTECTOR™

with Key Lock

Read These Instructions Very Carefully!

Congratulations!

Your new Honeywell Firesafe will provide years of safe and secure storage for valuables and important documents. Your safe has been built with the highest manufacturing standards to ensure maximum user satisfaction under a variety of conditions.

Package Contents

- 1 – Honeywell Media/Data Safe
- 1 – Operation & Installation Guide
- 2 – Entry Keys

Model 2040 Only

- 1 – Set of Easy Roller™ Wheels
- 1 – Easy Roller™ Wheels Assembly Instructions



Proper Use of Your Safe


- The Media Protector™ prevents damage to film, photographs, CD-ROMs, DVD-ROMs, computer & video tapes, and other media, which start to deteriorate at 150°F (65°C). It withstands 1700°F (926°C) for 1 hour while maintaining an interior temperature below 125°F (52°C).

For the safe to perform properly:

- Store the safe on a flat surface (or, if provided, the wheeled cart).
- Do not store or place the safe upside-down or on its side.
- Store the safe on a ground floor, in a location free of potential hazards and falling objects.

Important: ALWAYS STORE SAFE FLAT

Always store your safe in a flat horizontal position so that the contents remain protected during a fire. Storing the unit on the sides or ends **WILL NOT PROTECT CONTENTS** during a fire.



For Your Protection

- Always store keys away from (AND NEVER INSIDE) safe.
- Save this manual and NEVER keep it inside the safe.


Important: DO NOT RETURN SAFE TO STORE

If you have any questions pertaining to proper use, **DO NOT RETURN** safe to the store. Please Contact Customer Service at 1-800-223-8566 (USA & Canada).

Opening & Closing Your Firesafe


Opening Your Honeywell Safe

1. Insert the key and turn left.
2. Push the large button and the locking latch will open and spring forward.
3. Once the latch has cleared the lip it was secured to, you can open the Firesafe lid.
4. Remove the interior top tray.



Closing Your Honeywell Safe

1. Install the interior top tray. The safe will not function properly during a fire if the tray is not installed. Do not place media you want to protect on top of the tray.
2. Flip the lock assembly up and over the clasp.
3. Press the bar down to lock the clasp.
4. Insert the key and turn right.
5. Remove the key.



Assembling Wheels (Model 2040 only)

If your safe includes Easy Roller™ Wheels, follow the assembly instructions included in the box. For your safety, the Maximum Weight Warning printed on the wheel cart should be upright and facing outward.

After assembly, carefully place the safe onto the wheel cart. Do not sit or stand on the Easy Roller™ Wheels. The maximum weight supported is 85 lbs (38.6 kg).

How to Contact Us

Phone: 1-800-223-8566

Monday through Friday, 8:00 am to 4:00 pm Pacific Standard Time

Email: CustomerService@HoneywellSafes.com.

In addition to the required information regarding your safe, you must include the best time and proper telephone number to reach you during our normal Customer Service hours. You should receive a reply response via e-mail or phone within 24 business hours or the following business day.

Mail: Attn: Customer Service Dept.
SISCO
2835 E. Ana Street
Rancho Dominguez, CA 90221

Internet: www.HoneywellSafes.com

Ordering Replacement Keys

If a key becomes misplaced or you would like additional keys for your safe, you may conveniently purchase them from our Customer Service department.

Payment and Delivery

In the US, replacement keys are available for \$6.95 each and credit card orders are accepted by telephone and through our website. Checks or money orders are required for orders received by mail and should be made payable to "SISCO". Orders paid via money order or credit card typically ship within 72 hours. Orders placed with a personal or business check typically ship within 14 days.

You must supply the following information to assure accurate and prompt processing:

- Name / Address / Telephone
- Safe model number
- Number of keys requested
- Key number (located on the lock)

Terms subject to change without notice

Safe Identification Record

Your Safe's Unique Identification #'s

When contacting Customer Service, you should be prepared to supply some important information that specifically identifies your safe. This information is extremely important to assuring prompt and accurate assistance.

It is strongly recommended that you identify and record the following information in the "Identification Record" form located on the bottom of this page.

Model

The Honeywell Home and Office Security Safes product line consists of many different models, each identified by a specific Model #. Every model is manufactured with unique capabilities and features that may require specific solutions to a variety of difficulties that occasionally occur.

Key

The Key # is necessary to identify the specific configuration of the key and lock cylinder components of your safe. If a key becomes damaged or misplaced, the Key # is absolutely required to provide you with a replacement key.

Locating Key

The Key numbers are engraved on the keys and around the lock cylinder.

Your Safe Identification Record

Record all Safe Identification #'s below:

Model # 2040(NW)

Key # _____

Limited Warranty

LIFETIME AFTER FIRE REPLACEMENT GUARANTEE

If your Honeywell Firesafe is ever damaged by a fire, SISCO will replace it with a comparable model at no charge to the consumer. A photo of the damaged safe and a Fire Department report will be required as proof of loss. Freight on the replacement unit is not included in the guarantee and must be paid by the user.

LIMITED WARRANTY

If your Honeywell safe fails to operate because of a manufacturing defect, any time up to five (5) years from the date of original purchase, we will, at our discretion, repair or replace the unit at no charge to the original owner provided you return the product, shipping prepaid, to SISCO, or to a service center or locksmith of our choice. Prior authorization must be obtained from Sisco in advance.

WHAT IS NOT COVERED

This warranty does not apply if the product has been damaged by improper installation, neglect, accident, misuse, exposure to extremes of heat or humidity, terrorism, war, acts of God, or as a result of service or modification by other than an authorized service center. Sisco is not responsible for any costs associated with removing or installing this product. SISCO is also not responsible for damage or loss of the contents of the safe nor for the unauthorized removal of contents.

This warranty does not apply to the finish of any metal portions of the product. No other expressed warranty is given. The repair or replacement of the product is your exclusive remedy. Any implied warranty of salability or fitness is limited to the duration of this written warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. In no event shall SISCO be liable for consequential or incidental damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific rights and you may also have other rights which vary from state to state.

The Honeywell trademark for Home/ Office Safes is used with permission. Honeywell Safes are distributed exclusively by SISCO. Honeywell makes no representations or warranties with respect to this product or service, The Honeywell Trademark is used under license from Honeywell Intellectual Properties Inc. by SISCO.