



CO₂ sensor configuration settings

The following table shows the configurable items that can be changed in the Sensor software menus.

 **NOTE:** PLEASE MAKE A NOTE OF THE NEW CONFIGURATION SETTING IN THE NEW SETTING COLUMN NEXT TO EACH CONFIGURATION OPTION.

Item	Default setting	New setting	Comment
Alarm One Enabled	TRUE		Enable alarm
Alarm One Set-point	0.5		Threshold for the alarm
Alarm One Direction	Hi going		Can be set to either low going or high going
Alarm One Strobe Enable	Off		Activates the strobe on alarm
Alarm One Sounder Enable	Off		Activates the sounder on alarm
Alarm One Evacuation Enabled	Off		Activates the strobe and sounder of connected sensors on alarm
Alarm One Latching Enable	On		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Two Enabled	TRUE		Enable alarm
Alarm Two Set-point	1.50%		Threshold for the alarm
Alarm Two Direction	Hi going		Can be set to either low going or high going
Alarm Two Strobe Enable	On		Activates the strobe on alarm
Alarm Two Sounder Enable	Off		Activates the sounder on alarm
Alarm Two Evacuation Enabled	Off		Activates the strobe and sounder of connected sensors on alarm
Alarm Two Latching Enable	On		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Three Enabled	TRUE		Enable alarm
Alarm Three Set-point	3.00%		Threshold for the alarm
Alarm Three Direction	Hi going		Can be set to either low going or high going
Alarm Three Strobe Enable	On		Activates the strobe on alarm
Alarm Three Sounder Enable	On		Activates the sounder on alarm
Alarm Three Evacuation Enabled	On		Activates the strobe and sounder of connected sensors on alarm

Ax60+ CO2 Sensor Configuration Sheet

Int. Approved

Item	Default setting	New setting	Comment
Alarm Three Latching Enable	On		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Four Enabled	FALSE		Enable alarm
Alarm Four Set-point	3.50%		Threshold for the alarm
Alarm Four Direction	Hi going		Can be set to either low going or high going
Alarm Four Strobe Enable	Off		Activates the strobe on alarm
Alarm Four Sounder Enable	Off		Activates the sounder on alarm
Alarm Four Evacuation Enabled	Off		Activates the strobe and sounder of connected sensors on alarm
Alarm Four Latching Enable	On		Requires the user to mute and acknowledge the alarm before the alarm will clear